

SIGHT MARK



5x Tactical Magnifier with Slide to Side Mount

SPECIFICATIONS

Magnification, x	5
Objective lens diameter, mm	32
Eye relief, in/mm	2.1/54
Field of view, ft @100yd	23.6
Tube diameter, mm	30
Dimensions, in/mm	5.4 x 1.9 x 1.8 136 x 48 x 45
Weight, oz	12

Offering the ability to quickly move the magnifier out of the way without having to detach the unit, Sightmark® Slide-to-Side Tactical Magnifiers increase magnification of accompanying sights for greater sighting range and improved target acquisition. Each magnifier is designed for use with collimated reflex or other compatible weapons sights, giving the shooter the benefit of a reflex sight and scope in one combination.

FEATURES

- ✦ Improved rubber armor housing for increased durability
- ✦ Increases magnification of accompanying sights for greater engagement range
- ✦ Improved target recognition, especially medium range targets
- ✦ Internal windage/elevation adjustment for reticle alignment
- ✦ Slide to side mount provides rapid transition between weapon's optical systems
- ✦ Quick detach mount for easy on/off application
- ✦ Fully multi-coated optics
- ✦ Weatherproof
- ✦ EOTech® and Aimpoint® compatible

INCLUDED

- ✦ Slide to side mount
- ✦ Adjustment tools
- ✦ Manual